

DockSide Radio

Icom M802

User Group Channel / Memory Map

Ch N°	Receive Freq.	Ship Transmit Freq.	Mode	Label	Ch N°	Receive Freq.	Ship Transmit Freq.	Mode	Label
81	4006.0	4006.0	USB	S-S 4006	121	16531.0	16531.0	USB	Ship 16B
82	4009.0	4009.0	USB	S-S 4009	122	16534.0	16534.0	USB	Ship 16C
83	4012.0	4012.0	USB	S-S 4012	123	18825.0	18825.0	USB	Ship 18A
84	4015.0	4015.0	USB	S-S 4015	124	18828.0	18828.0	USB	Ship 18B
85	4018.0	4018.0	USB	S-S 4018	125	22159.0	22159.0	USB	Ship 22A
86	4021.0	4021.0	USB	S-S 4021	126	22162.0	22162.0	USB	Ship 22B
87	4024.0	4024.0	USB	S-S 4024	127	25100.0	25100.0	USB	Ship 25A
88	4027.0	4027.0	USB	S-S 4027	128	25103.0	25103.0	USB	Ship 25B
89	4030.0	4030.0	USB	S-S 4030	129	3696.0	3696.0	LSB	Bahamas Net
90	4045.0	4045.0	USB	S-S 4045*	130	3815.0	3815.0	LSB	West Caribbean
91	4060.0	4060.0	USB	S-S 4060	131	3820.0	3820.0	LSB	Bay of Islands
92	6224.0	6224.0	USB	Ship 6A	132	3856.0	3856.0	LSB	Taco 385 Net
93	6227.0	6227.0	USB	Ship 6B	133	3930.0	3930.0	LSB	Puerto Rico/VI WX
94	6230.0	6230.0	USB	Ship 6C	134	3964.0	3964.0	LSB	Waterway Net
95	6516.0	6516.0	USB	Ship 6D	135	3968.0	3968.0	LSB	Sonrisa Net
96	6212.0	6212.0	USB	S-S 6212	136	7158.0	7158.0	LSB	Caribbean Net
97	8294.0	8294.0	USB	Ship 8A	137	7163.0	7163.0	LSB	Caribbean WX Net
98	8297.0	8297.0	USB	Ship 8B	138	7185.0	7185.0	LSB	Barbados Net
99	8101.0	8101.0	USB	S-S 8101	139	7197.0	7197.0	LSB	South Pacific Net
100	8104.0	8104.0	USB	S-S 8104	140	7200.0	7200.0	LSB	Taco 720 Net
101	8107.0	8107.0	USB	S-S 8107	141	7233.5	7233.5	LSB	Baja Net *
102	8110.0	8110.0	USB	S-S 8110	142	7250.0	7250.0	LSB	Gordo's Net
103	8116.0	8116.0	USB	S-S 8116	143	7233.5	7233.5	LSB	Baja Net
104	8119.0	8119.0	USB	S-S 8119	144	7268.0	7268.0	LSB	Waterway Net
105	8122.0	8122.0	USB	S-S 8122	145	7270.0	7270.0	LSB	South Atlantic Net
106	8125.0	8125.0	USB	S-S 8125	146	7285.0	7285.0	LSB	Hawaii AM Net
107	8131.0	8131.0	USB	S-S 8131	147	7290.0	7290.0	LSB	Hawaii PM Net
108	8137.0	8137.0	USB	Caribbean WX	148	7292.0	7292.0	LSB	Florida Net
109	8152.0	8152.0	USB	Cruzhr Summer	149	7294.0	7294.0	LSB	Chubasco Net
110	8146.0	8146.0	USB	Cruzheimr Net Alt	150	14285.0	14285.0	USB	Calif/South Pacific
111	8164.0	8164.0	USB	Cruzheimr Net Alt	151	14300.0	14300.0	USB	24-hr Nets
112	6227.0	6227.0	USB	Cruzhr Winter	152	14303.0	14303.0	USB	Calif/Hawaii Net
113	6224.0	6224.0	USB	Cruzheimr Net Alt	153	14313.0	14313.0	USB	Hams on Ships
114	6230.0	6230.0	USB	Cruzheimr Net Alt	154	14325.0	14325.0	USB	Hurricane Net
115	8167.0	8167.0	USB	Panama Net	155	14330.0	14330.0	USB	Gunkhole Net
116	8188.0	8188.0	USB	NW Caribbean	156	14340.0	14340.0	USB	Mañana Net
117	12353.0	12353.0	USB	Ship 12A	157	21325.0	21325.0	USB	Atlantic Net
118	12356.0	12356.0	USB	Ship 12B	158	21390.0	21390.0	USB	Halo Net
119	12359.0	12359.0	USB	Ship 12C	159	21402.0	21402.0	USB	Pacific Net
120	16528.0	16528.0	USB	Ship 16A	160	28400.0	28400.0	USB	Ham Nets

Legend: Green = Transmit OK - Marine Radio License Rqd. Brown = Receive only - Entertainment

Freq. database Red = Safety comm. - Marine license Rqd.

Black = Receive only - Time & Propagation info.

Ver. 4/27/09

Violet = Receive only - Weather FAX

Blue = Transmit OK - Amateur Radio License Rqd.